


BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
001	OWNER'S MANUAL	1	084-961-011	210	PEDESTAL COVER - RIGHT	1	082-230-076
002	POLAR HEART RATE STRAP	1	3100-03A	211	STICKER - MODEL NUMBER	2	084-963-020
004	DISPLAY OVERLAY - NO CUTOUT	1	084-963-010	213	SCREW - P (M4*L12)	6	002-212-074
004A	DISPLAY OVERLAY - WITH CUTOUT	1	084-963-011	214	SCREW - P (M4*P0.7*L8)	6	002-211-223
005	NO 900MHz OVERLAY	1	000-063-970	215	SHOULDER COVER A - RIGHT	1	082-030-205
005.1	900MHz OVERLAY	1	000-063-980	217	SCREW - B/H (M5*P0.8*L12)	8	002-230-515
006	STICKER - BUTTONS	4	000-063-705	217R	WASHER - F (D10*D5.2*T1.0)	8	003-301-021
007	SMALL CAP	4	054-730-250	218	ZERK FITTING	2	E86-023
012	ENTERTAINMENT CAP	1	C545U-012	219	RUBBER HANDLE - RIGHT	1	E875-558
014	PLASTIC RIVET	1	C521M-093A	220	WATER GUARD	2	080-431-020
015	IPOD HOLDER	1	C545U-015	221	SHOULDER COVER B - RIGHT	1	082-030-215
016	SCREW - M/P (M4*L10)	2	002-210-002	223	STICKER - STRIDE	1	E875-564
019	SCREW - M/P (M4*L10)	2	002-210-002	224	STICKER - RIGHT	2	000-063-047
020	SCREW BRACKET	2	C575U-020	225	STICKER - LEFT	2	000-063-046
021	SCREW - M/P (M4*L10)	6	002-210-002	226	PEDAL CARRIAGE - NEW	1	184-050-04K
025	SCREW - M/P (M4*L12)	2	002-210-003	227	SCREW - P (M4*P0.7*L8)	8	002-211-223
026	MAGAZINE HOLDER	1	C545U-026	228	SCREW - P (M4*P0.7*L14)	4	002-211-067
029	STICKER - QR CODE	1	C575U-013	231	FOOT PEDAL - RIGHT	1	E83-96
030	SUPPORT PLASTIC	2	C545U-030	231R	FOOT PEDAL CUSHION - RIGHT	1	E822-069
031	SCREW - M/P (M4*L12)	7	002-210-003	232	SCREW - M/H (M5*L16)	8	002-203-052
032	DISPLAY SUPPORT FRAME	1	E83-01	233	STICKER - RIGHT	1	000-063-047
033	SCREW - B/H (M6*L20)	3	002-202-032	234	STRIDE RAIL REAR OUTER COVER - R	1	E835-234
034	WIRE CLIP - (1/4")	1	000-076-430	235	STRIDE RAIL REAR INNER COVER - R	1	E835-235
035	SCREW - P (M5*P0.8*L8)	1	002-211-252	236	SCREW - M/P (M4*L12)	4	002-210-003
046	KEY CUSHION	21	032-630-280	237	SCREW - P (M5*P0.8*L12)	2	002-211-255
064	SCREW - P (M3*L8)	4	002-212-042	240	STICKER - RIGHT	1	000-063-047
097	SCREW - P (M3*L12)	2	002-212-045	242	SUPPORT FRAME COVER	2	E845-242
098	SCREW - P (M3*L8)	18	002-212-042	243	OVAL FRAME CAP	4	E835-243
117	SCREW - P (M3*L8)	2	002-212-042	244	WASHER - (D18*D8.5*T2)	4	103-305-012
154	SCREW - P (M4*L8)	2	002-212-070	245	SCREW - M/H (M8*P1.25*L25)	4	002-203-064
157	STICKER - NFC	1	000-063-125	247	STICKER - RIGHT	2	000-063-047
158	STICKER - NFC	1	000-063-126	249	STATIONARY HANDLE	1	E835-249
160	DISPLAY BACK PLASTIC	1	C545U-160	255	SCREW - M/H (M6*P1.0*L15)	2	002-203-023
165	ZIP TIE	19	000-076-241	256	WASHER - F (D13*D6*t1.0)	2	003-301-034
167	STICKER	1	054-563-051	257	SCREW - B/H (M6*P1.0*L15)	2	002-205-614
168	STICKER - MEMBER CARD	1	C545U-168	258	WASHER - SU (D20*D7*T2.0)	2	E822-034B
171	BRACKET - RIGHT	1	C545U-171	260	SCREW - P (M4*L12)	4	002-212-074
172	SCREW - M/P (M4*L12)	4	002-210-003	263	NUTSERT - (M10)	4	001-107-020
173	DISPLAY SIDE COVER - RIGHT	1	C545U-173	264	WIRE CLIP - (3/8")	1	000-076-450
174	SCREW - P (M4*P0.7*L12)	4	002-211-225	265	SCREW - P (M5*P0.8*L12)	1	002-211-255
175	BRACKET - LEFT	1	C545U-175	266	LOWER FRAME COVER	1	E835-266
176	DISPLAY SIDE COVER - LEFT	1	C545U-176	267	STICKER - LEFT	2	000-063-046
178	CARD GUIDE COVER	1	C545U-178	268	NUTSERT - (M8)	4	001-107-010
202	SCREW HOLE CAP	1	C575U-314	276	SNAP RING - (STW-20)	1	004-401-006
203	SCREW - B/H (M10*P1.5*L20)	2	002-202-045	277	CRANK BUSHING	1	E822-089
204	WASHER - S (D20*D10.2*T2.0)	6	103-304-072	278	SCREW - H (M5*L5)	1	002-204-064
205	SCREW - M/H (M10*P1.5*L25)	6	002-203-072	279	SPINDLE BEARING - (6204ZZ)	2	8003-73
206	SCREW - P (M4*P0.7*L8)	2	002-211-223	280	WASHER - W (D45.5*D33.7)	1	003-303-003
207	SLEEVE	2	8300-32	281	STICKER - WARNING	2	082-063-030
208	PEDESTAL COVER - LEFT	1	082-230-067	282	LEVELER FOOT - (M10*P1.5)	2	032-653-050
209	SCREW - M/P (M4*L12)	5	002-210-003	283	NUT - H (M10*P1.5*H6)	2	001-102-140


BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
284	WHEEL AXLE	1	081-313-191	361	PLASTIC COVER	2	E875-555
285	TRANSPORT WHEEL	1	XT20-41	362	WIRE SET PLATE	2	180-410-460
286	SNAP RING - (9MM)	2	004-402-005	363	SCREW - P (M4*L8)	4	002-212-070
292	ALTERNATOR	1	G575U-223A	364	WIRE BRACKET	2	080-430-310
293	SCREW - P (M5*P0.8*L12)	2	002-211-255	366	SCREW - P/M (M4*L16)	4	002-210-013
295	SCREW - B/H (M6*P1.0*L15)	1	002-205-613	367	RUBBER HANDLE - LEFT	1	E875-619
296	WASHER - F (D15*D6.5*T3.0)	1	003-301-004	371	STICKER - LEVEL	1	E875-614
297	WASHER - F (D17*D8.3*T2)	1	003-301-038	374	HTR CONTACT PAD	2	E86-27
298	SCREW - B/H (M8*P1.25*L20)	2	002-205-820	382	SNAP RING - (STW-25)	2	004-401-007
299	WASHER - S (D18*D8.5*T2.0*19T)	1	003-304-063	383	WASHER - A (D32.2*D24.2*T1)	4	080-410-230
302	SCREW - B/H (M5*P0.8*L15)	3	002-205-516	384	WASHER - W (D33*D26)	4	003-303-004
305	STICKER - GROUND WIRE	1	000-063-002	385	WASHER - A (D32.2*D24.2*1)	2	080-430-200
310	STICKER - FRAME	1	082-663-021	386	BEARING	4	E875-572
311	SCREW - P (M4*P0.7*L8)	2	002-211-223	387	WASHER - A (D32.2*D24.2*1)	2	080-430-200
312	WASHER - F (D8*D4*T1.0)	2	003-301-017	388	WASHER - A (D32.2*D24.2*T1)	2	080-410-230
314	SCREW - P (M5*P0.8*L12)	2	002-211-255	390	SCREW PLUG	2	E82-75
316	PLASTIC SLEEVE (D9*D5.1*L8)	2	030-141-013	391	SCREW - P (M4*P0.7*L6)	4	002-211-076
317	MODEL BOARD BRACKET	1	C575U-461	392	STRIDE ADJUST COVER	2	E875-575
318	SCREW - P (M4*P0.7*L12)	2	002-211-225	393	BOLT - GUIDE ROLLER	2	805P-17
319	WIRE CLIP - (3/8")	1	000-076-450	398	STRIDE RAIL END CAP	2	805P-26
319R	SCREW - P (M4*P0.7*L12)	1	002-211-232	399	WHEEL & BEARING - 6000ZZ	2	E850-020
320	RUBBER BLOCK	1	E83-89	400	BUSHING - METAL	4	087-515-250
321	SCREW - P (M5*P0.8*L12)	2	002-211-255	401	NUT - H/N (M8)	2	001-101-080
322	BATTERY BRACKET	1	184-910-550	402	WASHER - F (D22*D8.5*T3.0)	2	003-301-056
323	SCREW - P (M5*P0.8*L12)	2	002-211-255	403	ROLLER COVER - OUTER - LEFT	1	082-030-265
327	STICKER - BATTERY	1	082-363-050	404	ROLLER COVER - INNER - LEFT	1	082-030-275
328	NUT - H (M8)	1	001-102-120	406	BUSHING	4	000-004-928
329	SCREW - B/H (M8*L60)	1	002-205-863	406S	HEX LINKAGE	2	084-013-070
330	WASHER - F (D20*D8*T2.0)	2	003-301-028	406T	SCREW - H (M8*P1.25*L17)	4	002-240-817
331	NUT - H/N (M8)	1	001-101-080	406U	BUSHING	4	087-513-240
332	SCREW - B/H (M8*P1.25*L20)	1	002-205-820	406V	BUSHING	4	000-004-481
333	FLYWHEEL	1	184-951-010	407	PEDAL CARRIAGE - NEW	1	184-050-04K
334	FLYWHEEL HARDWARE	2	051-810-080	408	WASHER - F (D21*D10.5*T2)	2	003-301-001
335	NUT - H (3/8")	2	001-102-042	409	NUT - H/N (M10)	2	001-101-030
339	STRIDE LINK COVER	2	805P-39	410	BOLT & NUT	2	082-013-090
340	SCREW - B/H (5/16"*L2-1/4")	2	002-205-910	411	FOOT PLATE AXLE	2	082-013-071
341	WASHER - F (D20*D8*T2.0)	2	003-301-028	412	BUSHING	4	000-004-900
342	LINKAGE BOLT	2	080-430-072	413	NUT - H/N (M5*P0.8)	4	001-101-070
345	SCREW - B (M5*P0.8*L8)	4	002-202-054	414	WASHER - F (D13*D6*t2.0)	4	003-301-045
346	SCREW - P (M3*L15)	4	002-212-046	415	PEDAL SUPPORT PLATE	2	182-010-243
347	WASHER - F (D7*D3.2*T0.5)	4	003-301-029	416	SCREW - P (M5*P0.8*L12)	4	002-211-255
348	SPACER (D5*D3.2*L7.9)	4	E850-227	417	WASHER - F (D13*D5.2*T1.0)	4	003-301-012
350	SCREW - P (M5*P0.8*L6)	7	002-211-251	419	STICKER - LEFT	1	000-063-046
351	CUP HOLDER - RIGHT	1	082-230-095	420	FOOT PEDAL - LEFT	1	E83-30
352	SCREW - P (M4*P0.7*L14)	1	002-211-067	420R	FOOT PEDAL CUSHION - LEFT	1	E822-282
353	CUP HOLDER	1	E835-353	422	PEDAL SUPPORT CUSHION - GREEN	2	082-031-013
354	CUP HOLDER - BOTTOM	1	E845-354	423	SCREW - M/H (M6*P1.0*L16)	4	002-203-021
355	CUP HOLDER - LEFT	1	082-230-085	424	SCREW CLIP	4	182-010-250
356	PIVOT COVER - LOWER	1	E835-356	425	NUT - H/N (M8)	2	001-101-080
357	SCREW - P (M4*L12)	2	002-212-074	426	BUSHING - METAL	4	087-515-250
358	SCREW - P (M4*P0.7*L8)	2	002-211-223	427	WHEEL & BEARING - 6000ZZ	2	E850-020

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
428	GUIDE ROLLER BUSHING	2	080-453-022	745	PEDAL SUPPORT CUSHION - GREEN	2	E875-791
429	BUSHING	4	E822-275	746	BOLT & BUSHING	2	E822-417
430	BOLT	2	805P-81	747	GUIDE ROLLER BOLT & NUT	2	181-891-270
433	SCREW - B/H (M6*P1.0*L15)	2	002-205-613	748	GUIDE ROLLER & SPACERS	2	E835-748
434	WASHER - F (D20*D6.3*T1.5)	2	003-301-007	750	STRIDE COVER - LEFT	1	E835-750
436	STICKER - LEFT	1	000-063-046	751	STRIDE RAIL	1	E835-751
437	STRIDE LINKAGE BOLT - REAR	2	E83-88	752	STRIDE RAIL BOLT	2	E83-97
440	STICKER - OPTIC SENSOR	1	805P-100	753	STOPPER	2	S916-441
442	DRIVE SPINDLE	1	805P-65	756	STRIDE ARM ASSEMBLY - LEFT	1	184-591-560
443	SCREW - B/H (M6*L20)	4	002-202-032	757	STRIDE GRIP ASSEMBLY - LEFT	1	E845-757
444	ROTATING CRANK BRACKET	2	E83-44	758	LEVEL SWTICH - LEFT	1	E875-785
445	SCREW - P (M5*P0.8*L12)	6	002-211-255	759	SHOULDER COVER - LEFT	1	E845-759
452	IDLER PULLEY AXLE	1	C545U-361	760	STRIDE MOTOR - LEFT	1	805P-12
454	WASHER - F (D17*D8*T2.0)	2	020-110-020	761	STRIDE LINK COVER - LEFT	1	E835-761
455	SCREW - B/P (M6*P1.0*L12)	2	002-207-150	762	GUIDE ROLLER - LOWER	1	805P-16
456	WASHER - F (D15*D6.5*T3.0)	2	003-301-004	763	GUIDE ROLLER BOLT & NUT	1	E835-763
457	SCREW - B/H (M6*P1.0*L15)	2	002-205-613	764	CUP HOLDER - COMPLETE	1	184-591-640
458	IDLER PULLEY BRACKET	1	E850-090	765	CUP HOLDER - LEFT	1	E845-765
459	IDLER STOPPER	1	E80-115	766	CUP HOLDER - RIGHT	1	E845-766
460	IDLER PULLEY SPRING	1	E83-41	767	CUP HOLDER - BOTTOM	1	E835-767
461	IDLER STOPPER BUSHING	1	E80-29	768	LINKAGE BOLT ASSEMBLY	2	805P-40
462	BUSHING	2	000-004-910	769	STRIDE LINKAGE - LEFT	1	E83-69
464	SCREW - B/H (M5*P0.8*L12)	4	002-230-515	770	STRIDE LINKAGE REAR BOLT	2	E822-424
467	STICKER - SPORTSART	2	000-063-820	774	PEDESTAL	1	E845-774
468	SCREW - P (M5*P0.8*L12)	6	002-211-255	775	STRIDE ARM ASSEMBLY - RIGHT	1	184-591-750
470	REAR CENTER COVER	1	E835-470	776	SHOULDER COVER - RIGHT	1	E845-776
472	SCREW - P (M5*P0.8*L12)	5	002-211-255	777	STRIDE GRIP ASSEMBLY - RIGHT	1	E845-777
476	WASHER - SPINDLE (D27*D17.2*T0.5)	2	051-810-180	778	STRIDE MOTOR - RIGHT	1	805P-05
477	WASHER - W (D23.2*D17.7)	2	003-303-019	779	STRIDE SWTICH - RIGHT	1	E875-804
480	WASHER - F (D20*D6.3*T1.5)	2	003-301-007	780	STRIDE LINK COVER - RIGHT	1	E835-780
481	SCREW - M/H (M6*P1.0*L15)	2	002-203-023	781	STRIDE LINKAGE - RIGHT	1	E83-82
483	ROTATING CRANK COVER	2	E835-483	782	STRIDE COVER - RIGHT	1	E835-782
484	COVER STRIP	2	E835-484	783A	PEDAL ASSEMBLY	1	184-591-831
491	STRIDE RAIL REAR INNER COVER - L	1	E835-491	785	LINKAGE KNUCKLE ASSEMBLY	2	E845S-785
492	STRIDE RAIL REAR OUTER COVER - L	1	E835-492	791	ROTATING CRANK COVER	2	184-591-910
493	ASSEMBLY CARD	1	E835-493	792	SIDE COVER - LEFT	1	184-991-920
494	WIRE CLIP - (3/8")	1	000-076-450	792.1	SIDE COVER - RAW - LEFT (INCLUDE	1	082-030-035
495	SCREW - P (M5*P0.8*L8)	3	002-211-252	793	SIDE COVER - RIGHT	1	184-991-930
701A	DISPLAY ASSEMBLY - COMPLETE - 900MHZ	1	184-991-010	793.1	SIDE COVER - RAW - RIGHT (INCLUDE	1	082-030-045
702	DISPLAY ASSEMBLY - FRONT	1	184-991-020	794	LINKAGE KNUCKLE	2	E835-794
703	ENTERTAINMENT CAP	1	C545U-703	795	SPINDLE WEDGE PIN	2	181-891-250
708	HEADPHONE JACK	1	T652-448	796	DRIVE PULLEY	1	805P-64
708A	HEADPHONE JACK - V2.0	1	158-691-080	797	SPINDLE & PULLEY	1	E835-797
709A	DISPLAY FRONT & OVERLAY	1	184-991-090	798	SPINDLE & PULLEY (WITH TOOL)	1	E825-162
713	DISPLAY ASSEMBLY - BACK	1	184-991-130	799	IDLER PULLEY	1	E83-48
714	SCREW & BUSHING	4	C575U-714	801	STATIONARY HANDLE COVER - LEFT	1	E845-801
721	DISPLAY BACK ASSEMBLY	1	E835-721	802	SUPPORT ARM - LEFT	1	E845-802
741A	PEDAL ASSEMBLY	1	184-591-831	803	FLYWHEEL ASSEMBLY	1	184-991-030
742	PEDAL SUPPORT PLATE	2	E83-31	803.1	DRIVE BELT - (500J8)	1	E83-50
743	PEDAL CARRIAGE BOLT	2	181-891-230	804	SUPPORT ARM - RIGHT	1	E845-804
744	PEDAL SUPPORT PLATE AXLE	2	E83-32	805	STATIONARY HANDLE COVER - RIGHT	1	E845-805

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
807	LEVELER FOOT	2	G572U-429				
810	MAIN FRAME	1	184-591-100				
812	LEVELER FOOT	1	S770-427				
813	LEVELER FOOT	2	C570U-69				
814	TRANSPORT WHEEL AXLE	1	E83-64				
815	WIRE - BATTERY CHARGER	1	E862-433				
816	PEDESTAL COVER ASSEMBLY	1	184-591-160				
821	MODEL BOARD ASSEMBLY	1	187-591-540				
822	ALTERNATOR	1	184-991-220				
823	BATTERY - 12V 4.5A (2 PIECE SET)	1	187-291-110				
823.1	WALL CHARGER - 32V	1	<-----				
824	WIRE - BATTERY TO DRIVE BOARD	1	E872-413				
825	WIRE - GROUND	1	C521U-436				
A01	WIRE - BLUETOOTH BUTTON	1	C575U-010				
A02	USB BOARD	1	C575U-063				
A04	HTR RECEIVER BOARD	1	C575U-044				
A05	WIRE - HRC BOARD TO DISPLAY	1	C575U-043				
A06	HEADPHONE JACK - V2.0	1	061-920-051				
A07	WIRE - BOOTLOADER	1	C575U-101				
A08	WIRE - USB CHARGER	1	C575U-102				
A09	CSAFE BOARD	1	C575U-153				
A09A	CSAFE BOARD	1	C575U-153				
A10	WIRE - CSAFE & USB	1	C575U-155				
A11	DISPLAY CONTROL BOARD - V2.0	1	154-520-013				
A11A	DISPLAY CONTROL BOARD - V3.0	1	154-520-014				
A12	WIRE - DISPLAY TO PEDESTAL	1	E875-099				
A13	WIRE - LED LIGHT	1	S715-017				
A14	WIRE - DISPLAY TO HEADPHONE	1	058-627-040				
A25	HTR BOARD	1	061-620-093				
A26	WIRE - HTR TO DISPLAY	1	C575U-118				
A33	WIRE - STRIDE SWITCH	1	E86-111				
A35	WIRE - HEARTRATE CONNECTOR	1	E845-A35				
A36	WIRE - DISPLAY TO STRIDE	1	E875-604				
A37	WIRE - LEFT STRIDE HARNESS	1	805P-76				
A38	WIRE - RIGHT STRIDE HARNESS	1	805P-77				
A39	WIRE - DRIVE TO PEDESTAL	1	E875-244				
A40	DRIVE BOARD	1	E875-245				
A41	MODEL BOARD	1	057-820-062				
A42	WIRE - MODEL NUMBER	1	C575U-248				
A57	WIRE - STRIDE SET	1	E845-A57				
A59	OPTICAL SWITCH	1	805P-61				
A61	WIRE - HEARTRATE PAD	2	E86-25				
A62	WIRE - HEARTRATE CONNECTOR	2	E86-101				
A63	WIRE - KEYBOARD	1	082-027-020				
A64	WIRE - STRIDE SWITCH	1	E86-26				
A67	WIRE - BATTERY JUMPER	1	E872-345				
A68	WIRE - BATTERY TO DRIVE BOARD	1	E875-238				
A69	WIRE - DRIVE POWER	1	084-927-200				
A71	STICKER - FUSE 3A 110V	1	C545U-219				
A72	FUSE - 3A 110V	1	F3ST-01				
T701	HARDWARE KIT	1	184-991-990				




01



Owner's manual

02




HRC

No.	Diagram	Tool Needed
1	EAY-F103B	LED
2	EAY-F103C	
3	EAY-F103D	
4	CAQ-F101F	OPTION
5	CAT-F101F	OPTION
6	EAY-F101E	OPTION

A1

4




SA WELL+

5




iPod

7



External TV rack

OPTION



Grease gun kit


OPTION




Maintenance grease and oil

T701


Hardware kit




CHANGE DATE	CHANGE DESCRIPTION	CHANGE NO.	NAME	SportsArt FITNESS RESTRICTED USAGE , PLEASE DON'T FORWARD TO ANYONE WHO ISN'T AUTHORIZED		DRAWN BY	UNITS		MM		SALES BLOW UP DIAGRAM		DIAGRAM NO.		EAY-F103A-A	
2016.09.27	A1 iPod 爆炸圖由TBK-F101E改為CAT-F101F		林士文			VERIFIED BY										
							QTY		1							E845S
							VERSION		A1		XX					
							RATIO		1:12							



CHANGE DATE	CHANGE DESCRIPTION	CHANGE NO.	NAME	SportsArt FITNESS RESTRICTED USAGE , PLEASE DON'T FORWARD TO ANYONE WHO ISN'T AUTHORIZED	DRAWN BY		UNITS	MM	SALES BLOW UP DIAGRAM	DIAGRAM NO.	EAY-F103B-A
2015.07.03	△1 ⑪⑪②⑤②⑥③⑤ 移至 713		蔡鴻興				QTY	1	XX	MODEL	E845S
2015.09.22	△2 區分TV WAR 差異料件	02-20141036M 02-20141036T	林士文				VERSION	A3			
2018.02.23	△3 ⑪⑪ 控制板設變為 ⑪⑪A, 取消程式轉接板 ③, 故取消 707A	03-20151204T	黃柏勳				RATIO	1:8			



CHANGE DATE	CHANGE DESCRIPTION	CHANGE NO.	NAME	SportsArt FITNESS RESTRICTED USAGE , PLEASE DON'T FORWARD TO ANYONE WHO ISN'T AUTHORIZED	DRAWN BY		UNITS	MM	SALES BLOW UP DIAGRAM	DIAGRAM NO.	EAY-F103C-A	
2015.06.16	A0 新增左右標籤		蔡鴻興		VERIFIED BY		QTY	1		XX	MODEL	E845S
2016.05.05	A1 756 775 新增 B17 , 防止漆面破壞而造成螺絲頭鬆動		蔡鴻興				VERSION	A2				
2016.12.05	A2 新增 785		張又仁				RATIO	1:16				



CHANGE DATE	CHANGE DESCRIPTION	CHANGE NO.	NAME	SportsArt FITNESS RESTRICTED USAGE , PLEASE DON'T FORWARD TO ANYONE WHO ISN'T AUTHORIZED	DRAWN BY	UNITS	MM	SALES BLOW UP DIAGRAM	DIAGRAM NO.	EAY-F103D-A
2017.11.17	新增 440		郭文綾			QTY	1			E845S
					VERIFIED BY	VERSION	A1	XX	MODEL	
						RATIO	1:14			