

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
002	POLAR HEART RATE STRAP	1	3100-03A	280	PEDESTAL FRONT COVER - UPPER	1	080-003-0260
005	STICKER - QR CODE	1	000-063-128	280R	SCREW - M/P (M5*0.8*L12)	1	002-209-132
008	POWER BUTTON	1	168-130-120	281	PEDESTAL FRONT COVER - LOWER	1	080-003-0270
009	BUTTON SPRING	1	068-104-020	282	SCREW - M/P (M4*L12)	6	002-210-003
010	KEY CUSHION	1	032-630-280	283	PEDESTAL FRAME ASSEMBLY	1	180-005-021L
011	ENTERTAINMENT PORT COVER	1	090-003-0770	284	SCREW - B/H (M10*P1.5*L20)	2	002-202-045
012	STICKER - MODEL NUMBER	2	080-006-3100	285	SCREW - B/H (M10*P1.5*L25)	6	002-230-025
013	NYLON RIVET	1	000-076-851	286	WASHER - F (D21*D10.5*T1.5)	6	E872MA-127
014	USB PORT PLUG	1	068-130-160	287	SMALL COVER - UPPER	1	080-003-0111
015	STICKER	1	068-263-090	289	SCREW - M/P (M4*L16 D8.5)	3	002-210-004
016	PLASTIC COVER - LOWER DISPLAY	1	090-003-0240	292	SCREW - M/P (M5*0.8*L12)	4	002-209-132
017	SCREW - M/P (M4*L12)	3	002-210-003	293	SPACER	4	080-416-060
018R	FAN BAFFLE	1	050-033-0480	294	WASHER - F (D7*D3.2*T0.5)	4	003-301-029
024	SCREW - P (M4*L12)	3	002-212-074	295	SCREW - P (M3*L15)	4	002-212-046
024R	SCREW - P (M2.6*L6)	3	002-212-022	296	STATIONARY HANDLE	1	E880-83
025	SCREW - P (M4*L12)	2	002-212-074	297	SCREW - B/H (M6*P1.0*L15)	2	002-205-614
026	SCREW - P (M3*L8)	3	002-212-042	298	WASHER - SU (D20*D7*T2.0)	2	E822-034B
027	WATER GUARD	1	068-130-170	299	WASHER - S (BW5 3/16")	1	003-304-050
028	SCREW - P (M3*L8)	11	002-212-042	300	WASHER - SP (M5)	1	C521M-167
029	SCREW - P (M3*L8)	2	002-212-042	301	SCREW - P (M5*0.8*L12)	1	002-211-094
034	SCREW - P (M3*P0.5*L6)	6	002-211-212	302	PEDESTAL BACK COVER - UPPER	1	080-003-0280
035	SCREW - P (M3*L8)	5	002-212-042	303	PEDESTAL BACK COVER - MIDDLE	1	080-003-0290
039	SCREW - M/P (M4*L12)	12	002-210-003	304	PEDESTAL BACK COVER - BOTTOM	1	080-003-0300
043	SCREW - M/P (M5*0.8*L10)	2	002-209-138	309	STRIDE LINK COVER	2	805P-39
044	DISPLAY BACK ACCESS COVER	1	050-033-0410	310	SCREW - B/H (5/16"*L2-1/4")	2	002-205-910
048	ZIP TIE	1	000-076-240	311	WASHER - F (D20*D8*T2.0)	2	003-301-028
051	SCREW - B/H (M8*P1.25*L20)	6	002-205-820	312	STICKER - RIGHT	2	000-063-047
052	WASHER - SP (M8)	4	003-302-010	313	LINKAGE BOLT	2	080-430-072
053	WASHER - F (D17*D8.3*T2)	3	003-301-038	316	PIN SHEATH	2	E875-354
053R	WASHER - S (D18*D8.5*T2.0*19T)	1	003-304-063	318	WASHER - F (D20*D6.3*T1.5)	4	003-301-007
053S	GASKET - (D13*0.25-0.35)	1	053-530-320	319	SCREW - B/H (M6*P1.0*L15)	4	002-205-613
066	SCREW - M/P (M4*L12)	4	002-210-003	320	ZIP TIE	25	000-076-241
074	AIR DUCT	1	050-033-0151	321	FRONT FLAP	1	080-003-0250
075	SCREW - M/P (M5*0.8*L12)	2	002-209-132	323	SCREW COVER	2	068-130-870
076	RUBBER PAD	1	050-033-0430	324	SCREW - M/P (M5*0.8*L16)	8	002-209-134
077	SCREW - M/P (M5*0.8*L10)	4	002-209-138	326T	FOAM TAPE	5	000-065-151
078	PLASTIC TRAY	1	050-033-0420	326U	TAPE - SINGLE SIDED	4	000-065-180
079	PLASTIC COVER - TRAY BACK	1	050-033-0400	326W	FOAM TAPE - DOUBLE-SIDED	1	062-057-020
080	SCREW - M/P (M5*0.8*L12)	5	002-209-132	328	SCREW - M/P (M4*L12)	22	002-210-003
081	SCREW - M/P (M4*L8)	1	002-210-010	329	SCREW CLIP - (M4-L16)	4	1250-111
082	CUP HOLDER	1	050-033-0440	333	SCREW INSERT	2	000-076-820
181	SCREW - P (M4*P0.7*L8)	4	002-211-223	334	SCREW - P (M5*0.8*L12)	1	002-211-094
184	SCREW - P (M4*P0.7*L14)	2	002-211-067	335	WASHER - S (BW5 3/16")	1	003-304-050
186	PLASTIC SLEEVE (D9*D5.1*L8)	2	030-141-013	336	WASHER - SP (M5)	1	C521M-167
187	SCREW - P (M5*0.8*L12)	1	002-211-094	337	SCREW - P (M4*P0.7*L8)	8	002-211-223
188	WASHER - S (BW5 3/16")	1	003-304-050	338	A/V BRACKET	1	180-001-0611
189	WASHER - SP (M5)	1	C521M-167	339	SCREW - P (M5*0.8*L12)	1	002-211-094
218	SCREW - M/P (M4*L16 D8.5)	2	002-210-004	340	WIRE CLIP - (1/4")	1	000-076-430
219	ADAPTOR BRACKET	1	180-011-0460	341	SCREW - P (M4*P0.7*L12)	1	002-211-225
222	DRIVE BELT - (410J5)	1	080-000-5030	342	WASHER - F (D8*D4*T1.0)	1	003-301-017
246	SCREW - P (M5*P0.8*L15)	2	002-211-256	343	STICKER - GROUND WIRE	2	000-063-002

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
347	FRAME COVER	1	180-003-0350	466	SCREW - B/H (M8*P1.25*L20)	4	002-205-820
351	CRANK BUSHING	1	E822-089	491	SCREW - B/H (M6*P1.0*L15)	2	002-205-614
352	WASHER - W (D45.5*D33.7)	1	003-303-003	492	WASHER - SU (D20*D7*T2.0)	2	E822-034B
353	SCREW - H (M5*L5)	1	002-204-064	493	STICKER - RIGHT	5	000-063-047
355	SNAP RING - (STW-20)	1	004-401-006	496	SCREW - M/P (M5*0.8*L12)	2	002-209-132
359	CRANK ARM - LEFT	2	E880-61	497	END CAP	2	080-003-0130
360	WASHER - SPINDLE (D27*D17.2*T0.5)	2	051-810-180	498	SUPPORT ARM COVER	2	080-003-0430
361	WASHER - W (D23.2*D17.7)	2	003-303-019	499	SCREW - M/H (M8*P1.25*L15)	4	C572R-132
364	WASHER - F (D22*D8.2*T2)	2	003-301-042	500	WASHER - SP (M8)	4	003-302-010
365	SCREW - M/H (M8*P1.25*L15)	2	C572R-132	500R	WASHER - F (D17*D8.3*T2)	4	003-301-038
367	CAP	6	C51U-16	501	SCREW - M/P (M4*L12)	2	002-210-003
368	FINGER GUARD - RIGHT	1	180-001-041L	502	SCREW - P/M (M4*L16)	6	002-210-013
368R	WASHER - F (D13*D5.2*T1.0)	6	003-301-012	505	HEART RATE CONTACT PLATE	2	190-005-3060
369	SCREW - P (M5*P0.8*L8)	6	002-211-252	507	SCREW - B/H (M6*P1.0*L15)	10	002-205-614
380	SCREW - P (M4*P0.7*L12)	2	002-211-225	509	WASHER - F (D13*D6*t2.0)	8	003-301-045
382	SCREW - M/P (M4*L12)	16	002-210-003	510	SCREW - M/P (M4*L10)	4	002-210-002
383	SCREW - M/P (M4*L10)	8	002-210-002	511	WASHER - F (D20*D5*T1.0)	4	003-301-020
384	WASHER - F (D11*D4*T1.0)	8	003-301-030	512	WATER GUARD	2	080-003-0450
388	SCREW INSERT	5	000-076-820	513	PLASTIC COVER	2	E875-555
389	SCREW COVER	2	068-130-870	514	SCREW - M/P (M4*L10)	4	002-210-002
390	SCREW - M/P (M4*L16 D8.5)	6	002-210-004	515	WIRE SET PLATE	2	180-410-460
393	SCREW COVER	4	068-130-870	516	WIRE SET PLATE	2	082-430-300
395	SCREW - M/P (M4*L12)	18	002-210-003	517	RIGHT STRIDE COVER - RIGHT	1	080-003-0210
397	REAR COVER - BACK	1	080-003-0390	518	SNAP RING - (STW-25)	2	004-401-007
399R	SCREW CLIP - (M4-L16)	2	1250-111	519	WASHER - F (D33*D25.1*T0.5)	4	103-301-015
400	COVER FASTENER	6	068-130-010	520	WASHER - W (D33*D26)	2	003-303-004
426	FLYWHEEL WASHER	2	103-306-003	521	WASHER - F (D33*D25.1*T0.5)	4	103-301-015
427	NUT - H (3/8")	2	001-102-042	522	SCREW - B/H (M5*P0.8*L12)	8	002-230-515
428	SCREW - B/H (M6*L20)	4	002-202-032	523	WASHER - F (D10*D5.2*T1.0)	8	003-301-021
430	DRIVE BELT - GATES (1195)	1	E880-112	524	SCREW - M/P (M4*L10)	4	002-210-002
433	IDLER PULLEY BUSHING	1	082-413-030	527	RIGHT STRIDE COVER - LEFT	1	080-003-0190
434	WASHER - W (WW-10)	2	003-303-011	529	SCREW - P (M4*P0.7*L6)	4	002-211-076
435	WASHER - F (D16*D10.2*T1.0)	2	003-301-141	530	STRIDE ADJUST COVER	2	E875-575
444	SCREW - B/H (M6*P1.0*L15)	1	002-205-614	531	AXLE PIN	2	087-513-260
445	PLUG BRACKET	1	120-021-0420	532	STRIDE ARM AXLE	2	8300-20
446	STICKER - LEFT	2	000-063-046	537	NUT - H/N (M10)	2	001-101-030
447	SCREW - P (M5*P0.8*L8)	2	002-211-252	538	WASHER - F (D21*D10.5*T2)	2	003-301-001
448	SCREW - B/H (M8*P1.25*L20)	1	002-205-820	539	BUSHING	4	000-004-928
449	WASHER - SP (M8)	1	003-302-010	540	STRIDE MOTOR - RIGHT	1	805P-05
450	WASHER - F (D17*D8.3*T2)	1	003-301-038	541	ROLLER COVER B - RIGHT	1	082-430-041
451	SCREW - B/H (M10*P1.5*L120)	1	002-205-398	542	SCREW - P (M4*P0.7*L8)	12	002-211-223
452	SCREW - H (M10*P1.5*L22)	1	082-401-011	543	ROLLER COVER A - RIGHT	1	082-430-031
453	IDLER PULLEY AXLE	1	082-413-220	544	FOOT PEDAL - RIGHT - LOWER	1	080-003-0340
454	IDLER PULLEY SPRING	1	082-404-011	545	SCREW - M/P (M5*0.8*L12)	3	002-209-132
455	IDLER PULLEY BUSHING	1	082-430-312	547	SCREW - M/P (M4*L12)	8	002-210-040
456	END CAP	1	C51R-05	549	COVER FASTENER	4	068-130-010
457	FINGER GUARD - LEFT	1	180-001-040L	553	SCREW - M/H (M5*L16)	8	002-203-052
459	GLIDE RAIL ENDCAP	2	E875-447	554	LANDING STRIP INSET - BLACK	8	050-003-0012
463	GLIDE RAIL UPPER SPACER	2	080-413-272	555	NUT - H/N (M10)	2	001-101-030
464	GLIDE RAIL LOWER SPACER	2	080-413-201	556	WASHER - F (D21*D10.5*T2)	2	003-301-001
465	WASHER - F (D20*D8*T2.0)	2	003-301-028	561	STICKER - RIGHT	7	000-063-047

**E876-16****ELLIPTICAL - 16" TOUCHSCREEN
120VAC**

7/10/19


BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
564	BUSHING	4	000-004-900	763	IDLER PULLEY	1	E875-760
568	SCREW - P (M5*P0.8*L12)	4	002-211-255	764	SPINDLE CRANK	2	E872-435
569	WASHER - F (D13*D5.2*T1.0)	4	003-301-012	765	SPINDLE WEDGE PIN	2	181-891-250
570	BOLT & NUT	2	082-013-090	766	SPINDLE ASSEMBLY	1	187-591-620
570R	WASHER - F (D17*D8.3*T2)	2	003-301-038	767	SPINDLE	1	E880-59
571	NUT - H/N (M8)	2	001-101-080	768	REAR COVER TRIM - LEFT	1	180-009-1180
572	ROLLER BUSHING	2	8300-92	769	REAR COVER TRIM - RIGHT	1	180-009-1190
573	BUSHING	4	E822-275	780	SUPPORT ARM - LEFT	1	180-009-1200
574	GUIDE ROLLER BUSHING	2	E875-593	781	SUPPORT ARM SMALL COVER - LEFT	1	180-009-1210
575	SCREW CLIP	4	182-010-250	782	STRIDE ARM ASSEMBLY - LEFT	1	180-009-1220
577	SCREW - M/H (M6*P1.0*L16)	4	002-203-021	783	STRIDE ARM HANDLE - LEFT	1	180-009-1230
584	STICKER - LEFT	7	000-063-046	784	STRIDE GRIP - LEFT	1	180-009-1240
586	FOOT PEDAL - LEFT - LOWER	1	080-003-0320	785	FOOT PEDAL ASSEMBLY - LEFT	1	180-009-1250
594	LEFT STRIDE COVER - RIGHT	1	080-003-0180	786	FOOT PEDAL - LEFT - UPPER	1	180-009-1260
595	LEFT STRIDE COVER - LEFT	1	080-003-0200	787	ROLLER AXLE	2	182-391-230
596	STRIDE MOTOR - LEFT	1	805P-12	788	GUIDE ROLLER	2	8300-19
597	ROLLER COVER A - LEFT	1	082-430-011	789	STRIDE ARM UPPER COVERS - LEFT	1	180-009-1270
598	ROLLER COVER B - LEFT	1	082-430-021	790	PEDAL SUPPORT PLATE	2	E83-31
602	STICKER - LEFT	4	000-063-046	791	PEDAL SUPPORT CUSHION - GREEN	2	E875-791
704	DISPLAY BACK FRAME	1	180-009-1040	792	BOLT & BUSHING	2	E880-47
706	DISPLAY BACK PLASTIC	1	150-039-1050	793	GUIDE ROLLER BOLT & NUT	2	181-891-270
707	SPORTSART LOGO	1	169-091-080	795	GUIDE ROLLER	2	187-591-950
708	WAKE UP BUTTON	1	168-691-040	796	PEDAL SUPPORT PLATE AXLE	2	E83-32
709	HEADPHONE BOARD	1	169-091-770	797	PEDAL CARRIAGE BOLT	2	182-391-280
710	FAN COVER	1	169-091-760	798	STRIDE ARM LOWER COVERS - LEFT	1	180-009-1280
711	RESISTANCE TOGGLE SWITCH	1	190-009-1800	799	PEDAL CARRIAGE ASSEMBLY (NEW STYLE)	2	182-391-402
712	FAN ASSEMBLY	1	150-039-1060	800	LINKAGE KNUCKLE ASSEMBLY	2	182-391-420
734	WIRE - GROUND	1	180-009-1050	801	STRIDE ARM ASSEMBLY - RIGHT	1	180-009-1290
737	A/V BRACKET - FRONT	1	120-049-1100	802	STRIDE ARM HANDLE - RIGHT	1	180-009-1300
740	REAR COVER - FRONT	1	180-009-1070	803	STRIDE GRIP - RIGHT	1	180-009-1310
741	SIDE COVER - LEFT - COMPLETE	1	180-009-1080	804	FOOT PEDAL ASSEMBLY - RIGHT	1	180-009-1320
742	SIDE COVER GRILL - LEFT	1	180-009-1090	805	FOOT PEDAL - RIGHT - UPPER	1	180-009-1330
743	SIDE COVER - RIGHT - COMPLETE	1	180-009-1100	806	STRIDE ARM UPPER COVERS - RIGHT	1	180-009-1340
744	SIDE COVER GRILL - RIGHT	1	180-009-1110	807	SUPPORT ARM SMALL COVER - RIGHT	1	180-009-1350
745	SPORTSART LOGO	2	169-091-350	808	STRIDE ARM LOWER COVERS - RIGHT	1	180-009-1360
746	MAIN FRAME	1	180-009-1120	809	SUPPORT ARM - RIGHT	1	180-009-1370
748	MODEL BOARD ASSEMBLY	1	187-591-540	A101	HTR BOARD	1	061-620-095
749	TRANSPORT WHEEL & AXLE	2	C570R-48	A103	WIRE - HTR	1	080-002-7211
750	LEVELER	2	P755-489	A115	USB BOARD	1	090-012-0450
751	STRIDE RAIL BOLT	2	E83-97	A119	WIRE - POLAR RECEIVER B	1	090-002-7270
752	STRIDE RAIL	2	E880-51	A120	HTR RECEIVER BOARD	1	C575U-044
753	STRIDE RAIL LINKAGE BOLT	2	E880-57	A122	WIRE - RESISTANCE SWITCH B	1	090-002-7291
754	STRIDE LINKAGE BAR - LEFT	1	E880-56	A201	WIRE - HTR CONNECTOR	1	080-002-7280
755	STOPPER	2	A916-37	A202	WIRE - HEARTRATE PAD	2	E86-25
756	LINKAGE BOLT ASSEMBLY	2	805P-40	A203	WIRE - TO HANDLEBAR BUTTONS	1	080-002-7270
757	LEVELER FOOT	2	G572U-429	A204	WIRE - BUTTON CONNECTOR	2	080-002-7290
758	STRIDE LINKAGE BAR - RIGHT	1	E880-93	A205	HANDLEBAR BUTTON - RESISTANCE	1	150-035-1030
759	SMALL COVER - LOWER	1	180-009-1140	A206	HANDLEBAR BUTTON - STRIDE	1	190-005-1060
760	FRONT FOOT COVER	1	180-009-1150	A207	WIRE - HEARTRATE CONNECTOR	2	E86-101
761	FOOT COVER SUPPORT PLATE - LEFT	1	180-009-1160	A208	WIRE - GRIP BUTTON	1	080-002-7240
762	FOOT COVER SUPPORT PLATE - RIGHT	1	180-009-1170	A209	WIRE - BUTTON TO STRIDE MOTOR - LEFT	1	080-002-7251

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
A210	WIRE - BUTTON TO STRIDE MOTOR - RIGHT	1	080-002-7261	S003	DISPLAY CONTROL BOARD	1	056-420-080
A211	WIRE - PEDESTAL	1	080-012-7080	S004	BLUETOOTH BOARD	1	056-420-090
A301	WIRE - CSAFE TO PEDESTAL	1	020-032-7091	S005	WIFI ANTENNA	1	056-427-250
A302	AV BOARD	1	068-820-010	S006	WIRE - CONTROL TO BLUETOOTH	1	056-427-600
A304	WIRE - MODEL NUMBER	1	C575U-248	S007	WIRE - TV TO MOTHERBOARD	1	056-427-270
A305	DRIVE BOARD - 110V	1	E845-A40	S008	WIRE - AV	1	056-427-590
A306	WIRE - DRIVE TO PEDESTAL	1	087-627-140	T701	HARDWARE KIT	1	180-009-1990
A307	WIRE - FLYWHEEL TO DRIVEBOARD	1	E880-125				
A308	WIRE - ETHERNET	1	080-012-7110				
A309	WIRE - CABLE TV	1	080-012-7100				
A310	OPTICAL SWITCH	1	8007-39				
A311	WIRE - STRIDE SET	1	E872-240				
A313	WIRE - POWER TO DRIVE	1	E845-A49				
A314	POWER CORD PLUG	1	090-012-5022				
A315	FUSE BREAKER - 2AMP	1	000-025-240				
A316	WIRE - BREAKER TO SWITCH	1	050-042-7330				
A317	ON/OFF SWITCH	1	000-025-160				
A318	WIRE - EUP	1	080-012-7130				
A319	FILTER - 110V	1	E845-A47				
A320	WIRE - FILTER GROUND	1	T652-063				
A321	WIRE - FILTER TO EUP	1	080-012-7141				
A323	WIRE - EUP TO DRIVE	1	E845-A46				
A325	POWER CORD	1	E82-62				
A326	NTSC CONNECTOR	1	061-829-030				
J001	OWNER'S MANUAL	1	080-016-1010				
J003	STICKER - WARNING LABEL	1	050-046-3010				
J032	SCREW - M/P (M4*L12)	12	002-210-003				
J180	BRACKET OVERLAY	1	068-863-120				
J213	STICKER - POWER SWITCH	1	000-063-001				
J214	STICKER - LIVE WIRE	1	000-063-005				
J215	STICKER - GROUND WIRE	1	000-063-004				
J216	SCREW - P (M4*P0.7*L8)	2	002-211-077				
J239	STICKER - 2AMP	2	000-063-253				
J249	SCREW	1	080-001-010				
J250	WIRE CLIP - (3/8")	1	000-076-450				
J251	SCREW - P (M5*P0.8*L8)	1	002-211-252				
J252	DRIVE BOARD COVER	1	180-001-064L				
J256	SCREW - P (M5*P0.8*L12)	1	002-211-255				
J263	ZIP TIE	2	C545U-165				
J265	SCREW - P (M6*L8)	3	002-211-135				
J272	SCREW - P (M4*P0.7*L6)	2	002-211-076				
J701	DISPLAY ASSEMBLY - COMPLETE	1	180-019-1011				
J702	DISPLAY FRONT PLASTIC	1	180-019-1020				
J703	DISPLAY BOARD ASSEMBLY	1	150-019-1031				
J731	FILTER ASSEMBLY	1	180-019-1030				
J732	EUP BOARD	1	187-991-320				
J733	DISPLAY POWER BOARD	1	180-019-1040				
J736	AV BRACKET ASSEMBLY	1	180-019-1050				
J747	FLYWHEEL	1	180-019-1060				
S001	NFC RECEIVER BOARD	1	056-420-190				
S002	DISPLAY MOTHERBOARD	1	056-420-170				

OLD→NEW 


Please Note:
For E876 16in before S/N:0390793

1. If you haven't replaced ,and if
you want to replace,
please send for replacement.




TOUCH SCREEN ASSEMBLY SP





CHANGE DATE	CHANGE DESCRIPTION	CHANGE NO.	NAME	SportsArt FITNESS RESTRICTED USAGE , PLEASE DON'T FORWARD TO ANYONE WHO ISN'T AUTHORIZED	DRAWN BY		UNITS	MM	SALES BLOW UP DIAGRAM	DIAGRAM NO.	EBD-F103B-A
2019.06.19	A1 配合儀表板改防火材質，修改 J702 → J702A 並新增 J713 J714		張又仁				QTY	1	XX	MODEL	E876 16"
					VERIFIED BY		VERSION	A1			
							RATIO	1:10			



物料編號

CHANGE DATE	CHANGE DESCRIPTION	CHANGE NO.	NAME	SportsArt FITNESS RESTRICTED USAGE , PLEASE DON'T FORWARD TO ANYONE WHO ISN'T AUTHORIZED	DRAWN BY	UNITS	MM	SALES BLOW UP DIAGRAM	DIAGRAM NO.	MODEL	EBD-F101D-A
							1				
							A0				
							1:13				
					VERIFIED BY		XX				