

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
001	OWNER'S MANUAL	1	S922-001	072	BOTTLE HOLDER BRACKET	1	197-910-110
002	NOISE SUPPRESSOR	4	A983-23	073	FOAM STRIP	1	091-057-010
003	WASHER - R (D15*D7.5*T2)	2	003-308-010	074	SCREW - B/H (M8*P1.25*L20)	2	002-205-820
004	COTTER PIN	2	004-405-031	076	RUBBER FOOT	3	A911-10
005	PIN	2	090-553-031	078R	PASTIC RIVET	6	000-076-990
006	STACK GUIDE TUBE	2	A922-31	079	ISOLATOR	2	S912-085
007	WEIGHT PLATE BRACKET	1	190-510-24L	080	KEVLAR BELT - (175.6")	1	100-005-401
008	GUIDE RING	14	A912-15	089	STICKER - USAGE	1	S922-089
010	STACK STANDOFF	2	A926-16	090	STICKER - WARNING	1	DF-101-008
011	RUBBER CUSHION	2	A912-17	092	TOP COVER	1	192-430-020
012	NUT - H (M10*P1.5*H6)	2	001-102-140	093	COVER SCREW - (M6*P1.0*35)	21	002-213-036
013	ADJUSTMENT PLATE - GREY	1	190-510-27L	094	COVER WASHER - (D21.5*10.5)	17	DF-101-030A
014	STOPPER	2	090-553-020	094R	SPACER	4	098-013-100
016	SCREW - M/H (M10*P1.5*L15)	2	002-220-010	098	WASHER - SP (M12)	2	003-302-013
017	WASHER - SP (M10)	2	003-302-012	099	SCREW - B/H (M12*P1.75*L30)	2	002-205-230
018	PLATE STICKER - 1.5-3.0KG (GREEN)	1	S912-018	101	WASHER - F (D17*D8.3*T2)	4	003-301-038
019	MAGNET SOCKET	2	090-513-200	102	WASHER - SP (M8)	4	003-302-010
022	SCREW - H (M5*L6)	2	002-204-062	103	SCREW - B/H (M8*P1.25*L15)	4	002-205-812
028	BUSHING	2	A911-36	104	SCREW - B/H (M8*P1.25*L20)	2	002-205-820
029	UPPER COUNTERWEIGHT	1	A911-40	105	WASHER - F (D26*D8.3*T3)	2	003-301-027
030	20-POSITION TUBE	1	A912-27	106	BUSHING	2	090-515-050
032	PIN	2	004-404-014	107	BELT PULLEY	2	A911-03
033	WASHER - R (D20*D11.1*T2)	2	003-308-011	108	O-RING	2	000-076-688
034	COTTER PIN	2	004-405-031	109	PULLEY AXLE	2	090-513-111
035	CUSHION RING	2	A911-37	110	PIN	4	190-510-43L
036	GUIDE RING	4	A911-38	111	BELT TIGHTENING HARDWARE B	2	195-910-03L
037	SCREW -B/H (M8*P1.25*L18)	2	002-205-813	112	WASHER - SP (M6*T1.5)	8	003-302-002
038	WASHER - SP (M8*T2.0)	2	003-302-006	113	SCREW - B/H (M6*P1.0*L35 )	8	002-205-632
039	SCREW - B/H (M5*P0.8*L10)	2	002-205-510	114	BELT ROTATOR PIN B	2	S912-145
040	CABLE BRACKET	1	A911-055	115	BELT FIXTURE	2	S912-146
041	SET FORK	1	A912-26	116	BELT BRACKET	2	A922-71
042	LONG STACK GUIDE TUBE	2	A922-36	117	SCREW - M/P (M5*0.8*L8)	2	002-209-130
043	CUSHION RING	2	A911-41	118	BELT BRACKET	2	A933-51
044	SCREW - B/H (M5*P0.8*L25)	4	S972-030	123	PULLEY BRACKET - GREY	1	192-210-06L
047	PLATE STICKER - 5KG (GREEN)	1	S912-047	124	WASHER - SP (M8)	4	003-302-010
048	PLATE STICKER - 10-60KG (GREEN)	1	S911-048	125	SCREW - B/H (M8*P1.25*L20)	4	002-205-820
049	PLATE STICKER - 65-100KG (GREEN)	1	S911-049	127	ADJUSTMENT HARDWARE	1	S916-127
050	SCREW - B/H (M6*P1.0*L25)	4	002-205-622	128	NUT - H (M10)	1	001-102-141
051	WEIGHT STACK CUSHION	2	A911-48	129	SCREW - B/H (M8*P1.25*L20)	1	002-205-820
054	SELECTOR FORK - NO CORD	1	190-553-052	130	WASHER - F (D26*D8.3*T3)	1	003-301-027
055	NUT - H (M4*P0.7)	2	001-102-090	131	BUSHING	1	090-515-050
056	RETRACTING CABLE	1	DF-100-021	132	BELT PULLEY	1	A911-03
057	SCREW - P (M4*P0.7*L25)	2	002-211-080	133	O-RING	1	000-076-688
065	SCREW - B/H (M12*P1.75*L30)	2	002-205-230	134	PULLEY AXLE	1	090-513-111
066	WASHER - F (D22*D13*T1.0)	2	C575R-560	138	STICKER - ROUND	3	E850-177
067R	SINGLE-SIDED TAPE	2	000-065-350	139	SCREW - B/H (M8*P1.25*L20)	2	002-205-820
068	STICKER - WARNING	1	DF-101-020D	140	SCREW - B/H (M8*P1.25*L30)	1	002-205-831
069	SPACER	19	A916-04	144	COVER PLATE - GREY	1	S922-144G
069R	WASHER - SP (M6)	19	003-302-011	145	STOPPER	1	A922-12
070	NUT - H/N (M8)	2	001-101-080	146	RUBBER GRIP	1	P711-107
071	WASHER - F (D17*D8.3*T2)	4	003-301-038	147	BUSHING	2	A922-67

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
148	WASHER - W (D38*D30)	2	003-303-006	220	SCREW - B/H (M5*P0.8*L10)	2	002-205-510
149	CAM - LEFT	1	192-215-29L	221	SEAT POST SHEATH	1	A912-44
150	NUT - H (M10*P1.5*H6)	4	001-102-140	222	AXLE PIN	1	090-513-430
151	STOPPER	4	090-553-020	223	COTTER PIN - (1.2*22)	2	004-405-041
152	STICKER - RIGHT CAM	1	092-263-031	224	SPACER	2	UB521M-132
153	CAM - RIGHT	1	192-215-28L	225	SNAP RING - (6MM)	2	004-402-012
154	STICKER - LEFT CAM	1	092-263-021	226	SEAT SHOCK	1	S912-221
155	BEARING	8	A922-62	400	COVER ASSEMBLY	1	192-491-060
156	SPACER	2	A933-44	401	FRONT COVER - TOP	1	192-491-040
157	INNER RING	2	S922-157	402	FRONT COVER ASSEMBLY	1	192-491-020
159	STICKER - WARNING	2	082-063-030	403	TOP COVER - UPPER	1	S922-403
161	SCREW - B/H (M8*P1.25*L20)	4	002-205-820	404	FRONT COVER - LOWER RIGHT	1	S918-404
162	WASHER - F (D26*D8.3*T3)	4	003-301-027	405	FRONT COVER - LOWER LEFT	1	S918-405
163	BUSHING	4	092-213-190	406	REAR COVER ASSEMBLY	1	S916-406
164	PEDAL CARRIAGE BEARING	4	805P-101	407	REAR COVER - UPPER	1	S916-407
165	AXLE INSERT	2	S922-165	408	REAR COVER - LOWER	1	S916-408
167	RUBBER GRIP	2	S922-167	409	PLATE STICKER - 5-100KG (GREEN)	1	103-191-230
168	RUBBER BUMPER	2	A951-100	411	KEVLAR BELT & ISOLATOR - (175.6")	1	S922-411
169	SCREW - B/H (M8*P1.25*L130)	2	002-230-891	413	ADJUSTMENT HARDWARE	1	A915-10
172	HANDLEBAR RING	4	A931-40	414	PIN	2	A912-09
173	SPACER	2	S922-173	415	WEIGHT PLATE BRACKET	1	S912-415
174	RUBBER SPACER	2	A922-55	416	STACK PIN MAGNET	2	A912-23
175	END CAP	2	A933-41	417	STACK ADJUSTMENT PIN	2	190-591-050
176	SCREW - H (M5*L5)	6	002-204-064	418	STOPPER	2	A922-63
177	CAP	2	DF-100-080	419	WEIGHT PLATE - 5KG	19	S911-419
178	SCREW - P (M4*P0.7*L14)	2	002-211-067	420	STACK COUNTERWEIGHT	2	S912-420
179	WASHER - F (D12*D4.2 T1.0)	2	003-301-018	421	PIN	2	A911-44
180	KNOB LOWER COVER	2	090-930-104	422	CABLE BRACKET	1	S972-406
181	SPACER	2	053-213-082	423	WEIGHT PLATE BRACKET	1	S912-423
181R	WASHER - W (D11*D6.4)	2	003-303-010	424	COVER TUBE SPACER - GREY	2	S922-424G
182	O-RING	2	000-076-690	425	CUSHION RING	2	S911-425
183	SPRING	2	DF-101-135	426	SELECTOR FORK - W/CORD	1	A911-50
184	PIN	2	096-413-040	427	SELECTOR FORK - NO CORD	1	190-591-530
189	SCREW - M/H (M6*P1.0*L10)	2	002-220-612	428	BOTTLE HOLDER (NEW)	1	197-691-280
190	RUBBER COVER	1	A922-17	429	MAIN FRAME - GREY	1	192-491-29K
192	SCREW - M/H (M6*P1.0*L16)	4	002-203-021	430	RUBBER FOOT COVER	3	S911-430
197	SCREW COVER	2	C575U-430	431	PIN	1	S912-476
203	END CAP	1	A912-46	432	SEAT POST SHEATH	1	S912-478
204	SCREW - M/P (M5*0.8*L12)	2	S972-174	433	RUBBER COVER	1	S922-433
205	ADJUSTMENT KNOB	1	A921-55	434	END CAP	2	S911-433
207	WASHER - F (D17*D8.3*T1)	1	003-301-044	435	BELT PULLEY AXLE	3	S911-431
208	SNAP RING - (6MM)	1	004-402-012	436	PULLEY BRACKET - GREY	2	S922-436G
209	PIN	1	090-513-303	437	SET PLATE - GREY	1	S922-437G
210	SCREW - M/H (M8*P1.25*L25)	4	002-203-061	438	END CAP - GREY	3	193-691-630
211	WASHER - SP (M8)	4	003-302-010	439	BELT BRACKET	2	S922-439
213	SEAT PLATE - GREY	1	191-710-39L	440	CAM - LEFT	1	S922-440
214	SCREW - B/H (M8*P1.25*L20)	4	002-202-040	441	CAM - RIGHT	1	S922-441
215	WASHER - SP (M8)	4	003-302-010	442	BELT TIGHTENING HARDWARE B	2	A922-70
216	SCREW - M/H (M8*P1.25*L25)	4	002-203-061	443	STOPPER	4	A922-63
217	NUT - H/N (M8)	4	001-101-080	444	CAM ARM ASSEMBLY - GREY	2	192-491-44K
219	STICKER - POSITION	1	DF-103-208	445	CAM ARM - GREY	2	S922-445G

BBL	Description	QTY	Part Number	BBL	Description	QTY	Part Number
446	ADJUSTMENT PIN	2	192-291-180				
447	AXLE	2	192-291-111				
448	FLY ARM ASSEMBLY - GREY	1	S922-448G				
449A	FLY ARM - GREY	2	S922-449G				
450A	SMALL GRIP	2	S922-450A				
451A	SMALL GRIP ASSEMBLY	2	S922-451A				
452	SEAT CUSHION - BLACK	2	S912-471B				
453	GROUND ANCHORS	1	191-791-960				
454	SEAT CUSHION FRAME - GREY	1	S912-472				
455	SEAT POST	1	A915-71				
456	SEAT POST SHEATH	2	S912-474				
457	SEAT POST PIN	1	A921-45				
458	FLY ARM - GREY	1	192-491-58K				
460	COVER HARDWARE	17	191-091-010				

